



CUSTOM DOOR & MIRROR INC.

148/150 Milbar Boulevard. Farmingdale, N.Y. 11735
Tel: (631) 414 7725 . Fax: (631) 414 7729

How to install...

A JAMB BRACKET

Jamb bracket must be lined up plumb to the top pivot. Measure from the side wall and the front edge and make sure its approximately plumb. There is some adjustability in both directions so getting it close here is key. The door will not operate properly if top and bottom are not lined up.

Then mount one screw into the jamb in the large flat hole. Don't tighten completely yet. If desired, you can put a second screw into the wall. You can also place a second screw strait down through the floor if possible this step is not necessary since the jamb bracket is usually used when you can't drill into the floor materials. Set the door into the hole and then tighten down.

